



6270159	1	CLAMP
3858700	2	BOLT
9409245	3	RIVET
3919636	4	REINF ASM
3919635	5	REINF
3919633	6	CLAMP
3828549	7	RIVET

BATTERY INSTALLATION PROCEDURE

1. Position battery to underbody against stationary clamp 6 .
2. Position clamp 1 to battery and underbody and secure by assembling screw 2 thru clamp 1 and into reinforcement assembly 4 .