Pursue your passion here

P.O. Box 1368 · Effingham, IL 62401 · Worldwide: 217-540-4200 · FAX: 217-540-4800

Call Toll-Free U.S. & Canada 800-500-1500 · Web: www.mamotorworks.com · E-mail: mail@mamotorworks.com

©2005

Suggested Installation Instructions for # 603-136 (17234) Flat Passenger Dash Panel

Mid America's 603-136 (17234) Flush Glove Box Panel is an excellent way to change the appearance of your 1984-89 Corvette interior. Installation requires time and patience. Please read and follow these instructions for best results.

- 1. Remove top dash pad (Figure 1).
 - · Remove screws under lip of dash.
 - · Remove screws at defrost vent.
 - Carefully remove upper dash pad from position making sure that all fasteners have been removed. Dash pad
 may be stuck in place with factory sealer caulk. It may be necessary to gently tug the dash pad from its
 position.
 - If your Corvette is equipped with a non-Bose stereo system, disconnect speaker wires for the dash speakers. TIP: You may want to clean upper dash pad at this time. You will be able to access areas that are hard to clean with the dash pad installed.
- 2. Remove plastic trim from each side of dash pad.
 - Remove right hand trim pad at tabs (Figure 2).
 - Tabs located on the dash pad that hold the stock passenger dash panel in place must be removed to accommodate the new panel. You can save these tabs for reinstallation of the factory passenger dash panel, if you wish.
- 3. Remove A/C duct from original passenger dash panel.
 - Remove backing from double stick adhesive tape around A/C vent opening on the new dash panel and install A/C duct to new panel.
- 4. Install new dash panel in place (Figure 3).
 - Install plastic retainer strip into position. This strip secures the new panel to the outer side of the passenger dash.
- 5. Remove stock A/C vent duct hose. Compress the supplied duct hose and reinstall in place of the original duct hose.
- 6. Reinstall upper dash pad reversing the procedures in step #1.

