

take out both passenger tail lights to get access to the part.

the first photo is looking into a tail light hole. The cover is over the **solenoid**. The fastener on the left can stay attached. The cover appears to be a thick fiber material (very bendable). On the right of the cover is a black push pin. I could not get the pin to come out but pulled on the cover and it came off the pin.



when you flip the cover from right to left you will see the **solenoid**. I used a small flat head screwdriver and a little elbow grease to get the rubber attachments off the black attachments. Very easy. just be careful with the screwdriver and don't tear the rubber

This is the solenoid

attachments.

