

2006 CORVETTE WIRING DIAGRAM INDEX

PAGE	SECTION
1	AIR CONDITIONING
7	ANTI-LOCK BRAKES
11	ANTI-THEFT
16	BODY CONTROL MODULES
25	COMPUTER DATA LINES
29	COOLING FAN
31	CRUISE CONTROL
35	DEFOGGERS
37	ELECTRONIC MUFFLER
39	ELECTRONIC POWER STEERING
41	ELECTRONIC SUSPENSION
43	ENGINE PERFORMANCE 6.0 L VIN U
51	ENGINE PERFORMANCE 7.0 L VIN E
59	EXTERIOR LIGHTS
65	GROUND DISTRIBUTION
73	HEADLIGHTS
75	HORN
77	INSTRUMENT CLUSTER
81	INTERIOR LIGHTS
85	MEMORY SYSTEMS
93	NAVIGATION
95	POWER DISTRIBUTION
103	POWER DOOR LOCKS
107	POWER MIRRORS
111	POWER SEATS
119	POWER TOP/SUNROOF
125	POWER WINDOWS
127	RADIO
133	SHIFT INTERLOCK
135	STARTING/CHARGING
139	SUPPLEMENTAL RESTRAINTS
143	TRANSMISSION
147	TRUNK, TAILGATE, FUEL DOOR
153	WARNING SYSTEMS
155	WIPER/WASHER